

MedeA: Surface Tension: Ease the Tension in Surface/Interfacial Tension Calculations

Contents

- Introduction
- Surface Tension Usage
- Surface Tension Output

1 Introduction

MedeA Surface Tension computes the surface and interfacial tension of a range of liquids, molten materials, and interfaces. The module performs molecular dynamics using *MedeA LAMMPS* to evaluate the difference between the time averaged stress tensor components perpendicular and tangential to the interface direction defined by the xy-plane of the input slab model.

$$\gamma_{av} = \frac{L_z}{2} [\langle P_{zz} \rangle - \frac{1}{2} (\langle P_{xx} \rangle + \langle P_{yy} \rangle)] \tag{1}$$

Key Benefits

- Automated setup, execution, and analysis of LAMMPS molecular dynamics simulations for surface and interfacial tension calculations
- Handles model construction and assignment of forcefield atom types and charges in one unified environment so that there is no need to use external tools
- · Performs analysis of surface/interfacial tension with graphs showing convergence for a given simulation

Hint: The *MedeA Surface Tension* module works with molecular dynamics simulations using LAMMPS. Ab initio MD trajectories are not currently supported with the *Surface Tension* module.

2 Surface Tension Usage

The **Surface Tension** stage computes the stress tensor components during a molecular dynamics simulation in the canonical (NVT) ensemble.

To start with, your fluid model must be a slab model with interface planes perpendicular to the z-axis, and appropriate forcefield parameters assigned to all atoms:

REVENUES IN REFERENCE AND REVENUES Y	Atoms						
	Y	Z	Freeze	Occupancy	Spin	FF Atom Type	FF Charge
	0.440562	0.570188		1	0	0*	-0.806
	0.458511	0.583773		1	0	hw	0.403
	0.464172	0.56256		1	0	hw	0.403
	0.455429	0.610673		1	0	0*	-0.806
	0.476959	0.620932		1	0	hw	0.403
	0.450629	0.618252		1	0	hw	0.403
	0.871353	0.621564		1	0	0*	-0.806



You can insert the **Surface Tension** stage into any *MedeA LAMMPS* Flowchart. To get started quickly, load a template *Surface Tension* workflow from the *MedeA* Flowchart library:

- Click on the structure window containing your fluid system and select New Job... from the Jobs menu.
- In the Flowchart editor window that appears, click Open library... and select the file *Surface tension.flow* from the LAMMPS directory.

File Edit Builders Tools	Jobs Forcefields A	Analysis Winde	ows Help Custo	m								
	Select Server	•		1								
▲ * (C6O5H24)100 (P1) ~	View and Control	Jobs xande	erMavromaras/D									
	New Job											
	🗚 MedeA: prepare Job	b										
	Main >>		-	A one-line summar	y of this	flowchart!						
	Start	. A	Reading and write	ting flowcharts								
2.988 B.	Start)	Open Library	Open User S	ave							
1443.2D		4	From job:		1	Open						
100 C C C C C C C C C C C C C C C C C C	+		Floingou.			open						
		🔥 Open libra	ry flowchart				>	<				
114.43		Directory: C	:/MD/data/Flowch	arts.kit/LAMMPS			-	5				
1934 X893												
Y		Diffusion.f			Surfac	ce tension.flow						
4			uench.flow	MedeA: prepare Job	Therm	nal conductivity using Mueller Plathe.	flow					
Z_Z			oint of generic ma	fain		low Kubo.flow						
			position.flow	<u></u>								
			lecular dynamics.	Start		٨ MedeA: prepare Job						
				1		Main >> LAMMPS			Edit stage: Su	irface Ter	sion	
	9	•			、 '		T					
		Description:		Variables		Start	Minimize	Surface Tension	Control	Analysis		
	_	Surface	tension	tstep = 1 fs T = 298.15 K	7		Optimization of atom	Temp: \$T	Initial Tem	perature:	\$T	1
				P=1 atm		\checkmark	positions, Method: Steepest descents	Time: \$t_gamma Step: \$tstep				
			calculates the s	Ţ		+	Econvergence = 0.0	Control: Nose-Hoover	Final Temp	perature:	\$T	-
		Trajectories to		LAMMPS			Fconvergence = 1.0	Sampling: 10000 samples Trajectory: 20 frames	Time:		\$t_gamma	
						Initialize		Trajectory: 20 frames				
		Start with a st charges.	h model, perpen			muanze	ŧ	*	Time Step	:	\$tstep	-
			5				NVT	-	-Controls-			
		**************************************	····· ··· ···	÷		3-d periodic	Temp: \$T		Control:		Nose-Hoover	
		File name:	Surface tension			Cutoff: 14 Skin: 2.0	Time: \$t_eq_slab Step: \$tstep		·			1
		Elles of home	Elaurahanta (h.f.)			Long range: PPPM	Control: Nose-Hoover		Damping	(ts):	100.0	
		Files of type:	Flowcharts (*.flo	w) –		W/ tail corrections	Sampling: 10000 samples Trajectory: 0 frames		Drag (0.0	-> 2'ish):	1.0	
							majectory. o manies		Trajector			
									Sampling:	10000	sampl	es 🔻
						R			Trajectory	: 20	frame	s 🔹
						3						
											-	
							10.01	•			OK	K G

The *Surface Tension* workflow has one **LAMMPS** stage with four substages, namely **Initialize** to set some input parameters, **Minimize** to relax the system with fixed cell parameters, **NVT** to equilibrate, and **Surface Tension**, the production run, also in the NVT ensemble, to evaluate the stress tensor components. You can inspect and modify this Flowchart to fit your system and computational goals. Double-click the **LAMMPS** stage to see these substages. Double-click any substage to inspect and edit parameters. The parameters of the **Surface Tension** stage are:

- Initial Temperature: The initial temperature setpoint for the thermostat.
- Final Temperature: The final temperature setpoint for the thermostat.
- Time: The amount of time to use for the surface tension calculation.
- Time Step: The time step size employed in solving the equations of motion.
- Control: The thermostat algorithm to be used for the NVT ensemble.
- Sampling: The quantity of samples, steps, or time to use for gathering statistics.
- *Trajectory*: The quantity of frames, steps, or time that defines how often configurations are written to a trajectory file.

3 Surface Tension Output

After completing a *Surface Tension* simulation, results are written to *Job.out* and a plot of the surface tension evolution during the production run is stored in a stage subdirectory on the JobServer. The *MedeA Surface Tension* template Flowchart creates *gif* and *png* output, e.g., *<Job_number>/Stage 2/2.7_surface_tension.png*.



Stage 2.7: Surface tension calculation using NVT integration for 200 ps with a timestep of 1 fs, T is 298.15 K

Property	Value	+/-	Uncertainty	Units	After Steps	% Run
t:	200000			fs		
Т:	298.135	+/-	0.026	К	0	0.0%
Ρ:	-62	+/-	26	atm	0	0.0%
V:	38456.4	+/-	7.8e-10	Ang^3	0	0.0%
rho:	0.761066	+/-	0	q/mL	0	0.0%
Etotal:	-7165	+/-	32	kJ/mol	0	0.0%
Epot:	-18316	+/-	32	kJ/mol	0	0.0%
Ekin:	11151.06	+/-	0.96	kJ/mol	0	0.0%
Evdw:	1350			kJ/mol	0	0.0%
Ecoul:	-21160	+/-	69	kJ/mol	0	0.0%
Sxx:	109	+/-	26	atm	0	0.0%
Syy:	87	+/-	33	atm	0	0.0%
Szz:	-11	+/-	25	atm	0	0.0%
Syz:	2	+/-	8.2	atm	0	0.0%
Sxz:		+/-		atm	0	0.0%
Sxy:	6			atm	0	0.0%
Surface Tension:	35.9			mN/m	Ō	0.0%



